


# BE-LAPLACE

---

1. Unpack the file BE-LAPLACE.ZIP and click on the file setup.exe
2. The program is installed in the folder

C:\Programs (x86)\BE-STATIK1E\BE-LAPLACE

3. With the program the Visual Studio 2022 dll is downloaded from the Microsoft server if it is not installed.




You can also install the dll separately beforehand. Download the file vc\_redist.x86.exe from the Internet [https://aka.ms/vs/17/release/vc\\_redist.x86.exe](https://aka.ms/vs/17/release/vc_redist.x86.exe) and double-click on the file.

4. The program uses a Data Path. The Data Path is the name of a folder on your computer which you specify. It serves as the 'root folder' for the subdirectories SDIR... which contain the data files of the single positions. After the installation, the Data Path points to the directory

C:\Users\...\AppData\Roaming\BE- LAPLACE

The program cannot write to this folder to store your input. So, the first thing you should do is to specify a new Data Path. For this click on the button Path Data



and choose an existing folder as your data path or generate a new folder to which the program has write access.

5. The manual is included. Press the F1-Button or click on the tab Inst and next on Manual.

