


# BE-FRAMES

---

1. Unpack the file BE-FRAMES.ZIP and click on the file setup.exe
2. The program is installed in the folder

C:\Programs (x86)\BE-STATIK4E\BE-FRAMES

3. With the program the Visual Studio 2022 dll is installed (download from the Microsoft server) if it is not already present on the computer. After the installation you will see an entry for the dll in the list of installed programs.




You can also install the dll separately beforehand. Download the file vc\_redist.x86.exe from the MS-Server [https://aka.ms/vs/17/release/vc\\_redist.x86.exe](https://aka.ms/vs/17/release/vc_redist.x86.exe) and double-click on the file.

4. The program uses a Data Path. The Data Path is the name of a folder on your computer which you specify. It serves as the 'root folder' for the subdirectories SDIR... which contain the datafiles of the single positions. After the installation, the Data Path points to the directory

C:\Users\...\AppData\Roaming\BE-FRAMES

where the program cannot store data files. So, the first thing you should do is to create or set a new Data Path. Any folder to which the program has write-access is okay.

To set the Data Path click on the button Path Data



5. The manual is included. Click on the button **F1**.