



# BE-PLATES BE-SLABS BE-LAPLACE BE-FRAMES

If the program has not been installed on the computer, the data path after installation points to the directory where the program is installed. However, the program cannot store any data there. Therefore, change the data path.



To do this, click on the button Data path . The following window will open:



Go to the bottom line and enter


D:\P3DATA (or any other name or any other drive)

and press the Enter key (Return key). This then is your data path and the program stores the input of the individual positions (jobs) in this directory.

For control purposes, the program displays the current data path in the main menu

# BE-PLATES BE-SLABS BE-LAPLACE BE-FRAMES

---



Your should see your data path listed